

BR300/BR350 Borescope Inspection Camera




CE

Introduction

Congratulations on your purchase of the Triplett BR300/BR350 Borescope. The BR300/BR350 is a high performance industrial inspection camera with a 5-inch high definition color LCD. It is ergonomically designed so that the main function buttons can be controlled with one hand. The built-in 3000mah rechargeable lithium battery allows 3-4 hours of continuous operation. The snapshot and recording functions are supported, photos and videos can be saved on TF memory card (Micro-SD card). The camera focal length is 1.2" to 4.0" (3cm to 10cm). Model BR300 is a single forward looking camera system and the Model BR350 is a Dual forward and side view camera system.

Meter Description



Safety

This product is designed for industrial inspection camera.


- Avoid severe hits to the camera probe, and do not aggressively pull the cable.
- Please do not use it under high temperature, high magnetic environments or under strong light.
- Please use 5V household charger that meets the safety regulations to charge this device.
- Do not expose this product to extremely low or high temperatures
- If used for extended periods of time, please ensure that it is charged at least once every 3 months to prevent irreparable damage caused by excessive battery discharge.
- Do not wipe the unit with corrosive chemical wash.

NOTICE:

WARNING ! This product is an industrial inspection camera and is not intended for medical use or human examination.

ACCESSORIES INSTALLATION

The installation of accessories is shown in the following figures



Operation

BUTTON OPERATION

Power Button :

Press for 3 seconds to turn ON / OFF the screen.



Playback/Menu Button:

In live view, it functions as the *Menu* Button. Press to enter the settings menu. Press again to exit.

Playback : Press and Hold for 3 seconds to enter Photo or Video Playback, press again to exit.

Zoom:

In live view, Press to zoom 3X, press again to resume.

Screen Rotate

In live view, press it to screen rotate 180°, press again to resume screen rotate 180°.



OK Button :

In setup menu, press the OK button to confirm.

Freeze Screen Button :

In live view, press to freeze screen press again to exit.



Camera LED Button :

Press to control 3 levels brightness.



Auxiliary light switch:

In live view, Press to turn ON LED light . Press again to turn OFF the LED light .

Photo / Video Button :

Press to capture photo images Hold for 3 seconds to Start video recording / End video recording.

ENTER MENU SETTINGS

Date / time settings

Setting path:

button to enter the settings page Short press the Select first item (Date / Time) on settings page



button to select the Date / Time desired. Press the Press up and down keys to change the Date /Time you desire.

Press



to save the setting.

Language settings

The default language is English. The system supports English, Chinese, German, French, Spanish, Russian and Japanese.

Setting path:

button to enter setting page Short press the Select second item (Language) on settings page Press up and down keys to select the language desired.



to save the setting.

TF card format settings




Photo taking / Video recording / Playback

Press the for 3 seconds to switch to playback mode. Press up and down button to select photo or video to view,

Short press the button to enter delete mode of photo or Video. Press to confirm deletion of the photo or video.

Press the **for 3** seconds to exit playback mode.

Specifications

Model	BR300 (Single Camera) BR350 (Dual Camera)
Screen	5.0inch color LCD display
Resolution	1280*720 ; 1920*1080
Horizontal viewing	60°
angle	
Language	Simplified Chinese, Traditional Chinese,
	English, French, German, Italy, Russian,
	Japanese
Line length	5M 10M (Interchangeable)
Focal length	1.2" to 4.0" (3cm-10cm)
Waterproof level	IP67(only for camera head and lens)
Lens diameter	5.5mm
Battery capacity	3000mAh
Battery life	Approximately 3-4 hours

TROUBLESHOOTING:

Problem	Solution
The device does not	1. Use after fully charging the battery.
POWER ON	2. Confirm whether the power supply
	has been successfully connected

TF card reading failed	1. Confirm whether the TF card meets
	the requirements(the
	Highest supported format is 64GB
	Micro TF card in FAT 32,and the
	transmission speed must be Class 10 or
	higher)
	2. Remove the TF card and reinsert it.
After the device is	1. Reconnect the device and the PC
connected to	2. Confirm whether to enter mass
The PC, TF card not	storage mode
read.	
Blemishes or smudges	1. Clean the screen carefully with a soft
on the screen	cloth

Warranty

Triplett / Jewell Instruments extends the following warranty to the original purchaser of these goods for use. Triplett warrants to the original purchaser for use that the products sold by it will be free from defects in workmanship and material for a period of (1) one year from the date of purchase. This warranty does not apply to any of our products which have been repaired or altered by unauthorized persons in any way or purchased from unauthorized distributors so as, in our sole judgment, to injure their stability or reliability, or which have been subject to misuse, abuse, misapplication, negligence, accident or which have had the serial numbers altered, defaced, or removed. Accessories, including batteries are not covered by this warranty

Copyright © 2021 Triplett www.triplett.com